


# How to restore DEMO song

## Restoring DEMO song

1. Connect the unit to a computer using the USB cable.
2. Use the computer to copy DEMO song file from the computer to the BACKUP directory on the FAT partition of the unit.
3. When done copying, remove the USB cable using the proper procedures and disconnect the unit from the computer.
4. After the unit restarts automatically, press the **MENU** button to open the MENU screen.
5. Use the **DATA** wheel to select (highlight) the DATA BACKUP item, and press the **F4** [▶] button to open the DATA BACKUP screen.



6. Use the **DATA** wheel to select (highlight) the SONG RESTORE item, and press the **F4** [▶] button to open the SONG RESTORE screen.



This screen shows the backup files on the FAT partition.



### NOTE

A File Not Found (the file cannot be found) pop-up message appears if there are no files on the FAT partition.

7. Use the **DATA** wheel to select (highlight) the file that you want to restore, and press the **F2** [EXEC] button.

The actual song name and an Are you sure? confirmation pop-up message appear.



### NOTE

If the file name is short, spaces appear after the file name on the FAT partition, but those spaces are not included in the actual file name.

8. Press the **F3** [YES] button.

After the currently loaded song is saved, the song selected in step 7 is restored and loaded.


### NOTE

If there is not enough open space on the SD card, a Card Full pop-up message appears.



9. Press the **HOME** button to reopen the Home Screen.

## Listening to the demo song


1. Press the **HOME** button to open the Home Screen.



2. When the recorder is stopped, press the **MENU** button to open the MENU screen.




3. Use the **DATA** wheel to select (highlight) SONG, and press the **F4** [▶] button to open the SONG menu screen.




# How to restore DEMO song

- Use the **DATA** wheel to select (highlight) **LOAD**, and press the **F4** [▶] button to open the **SONG LOAD** screen that shows a list of songs.





- Use the **DATA** wheel to select (highlight) **DEMO\_8EX**, and press the **F2** [EXEC] button. The demo song loads and the **SONG** screen reopens.




- Press the **HOME** button to return to the Home Screen.
- Press the **Play** (▶) button and turn up the **TRACK 1-8 LEVEL** knobs, the **MASTER LEVEL** knob and the **VOLUME** dial on the back of the unit to until you can hear the demo song.

The **MASTER LEVEL** knob adjusts the volume of all eight tracks at the same time. The standard position of this knob is around 2-3 o'clock. Use the **TRACK 1-8 LEVEL** knobs to adjust the balance among the tracks. Use the **VOLUME** dial on the back of the unit to adjust the final monitoring level.



- Use the **TRACK 1-8 PAN** knobs to adjust the stereo positions of each track.



## TIP

- Press the ◀ [RTZ] button while pressing and holding the Stop (■) button to use the return to zero (RTZ) function to jump to the beginning of the song (00h00m00s00f).
- When using a menu, if you make a mistake pressing a button and the wrong screen appears, press the **HOME** button to return to the Home Screen.